

Switching Mode Universal Regulated USB power adaptor

Owner's Manual

Thank you for purchasing our product. Please read this manual carefully. It contains important operating instructions. This unit is specially designed for power up your USB devices with safe.

Standard Accessories:



Other Accessories: (option)




Fig. 1



Table A

						
Nokia 62380i	Nokia N70, N80	Motorola V3 Mini USB	Motorola V120	Sony Ericsson W700, K300c	Samsung D528	LG chocolate

Features :

- Charge and power Up your Digital devices by this AC adaptor (such as mobile phone, iPod, Mp3, Mp4, PDA/ DV/ DC & portable games devices) please see table A for the **compatible brand of cell phone**
- Power and charge your portable devices with a compatible 5V/1A power connection via your house hold electric outlet (100-240V AC)
- Short-Circuit protection design against damage for your USB devices
- Comply to Energy Saving requirement
- LED indicator

Safety Features :

- Short circuit protection

Charging your USB devices

1. Before using, check the USB device's input voltage and the AC adaptor's output voltage if they can match. Make sure the total loading does not exceed the rated output current of the AC adaptor.
2. Choose the suitable connector (from Accessory no.2 to no.3) and connecting USB cable (Accessory no.4). Connect the USB cable with your digital device and the DC output of the adaptor.
3. Plug the AC adaptor into household electric outlet (100-240V AC). The switching power supply will adjust automatically and the LED indicator will light on instantly.
4. Switch on your Digital device.

Specifications:

DC adaptor	Input:	100-240V AC 50/60Hz
	Output:	5V DC 1A

Important Safety Instructions

1. Do not short circuit the output terminals.
2. Ensure correct voltage is used as continuous excess voltage could damage your equipment.
3. Do not try to use this power supply with appliance requiring more than 1000mA.
4. Do not attempt to open this unit.
5. Remove from mains when not in use.
6. Always turn off the Digital device before you connect/ disconnect the AC adaptor.

SMP-500A005USB