

PowerAid™ Tip Compatibility Matrix

Apple

iPod

Blackberry

6210	6220	6230	6280	6510	7210	7230
7250	7270	7280	7290	7510	7520	7100g
7100i	7100r	7100t	7100v	7100x	7105t	7130e
8100 (Pearl)	8700c	8700f	8700g	8703e		

LG

4650	4700	5200	6100	KG800	KG900	LG2000
VX10	VX3100	VX3200	VX4400	VX4500	VX4600	VX6000
CHOCOLATE						

Motorola

A780	E1070	E770v	L6	PEBL	RAZRV3	RAZRV3i
RAZRV3x	SLVR	V360	V360v			

Samsung

SCH-A210	SCH-A310	SCH-A399	SCH-A475	SCH-A505	SCH-A509	SCH-A530
SCH-A539	SCH-A563	SCH-A564	SCH-A570	SCH-A591	SCH-A592	SCH-A595
SCH-A599	SCH-A610	SCH-A650	SCH-A670	SCH-A795	SCH-A809	SCH-N181
SCH-N181	SCH-N182	SCH-N191	SCH-N195	SCH-N288	SCH-N330	SCH-N370
SCH-N375	SCH-X199	SCH-X209	SCH-X309	SCH-X319	SCH-X359	SGH A561
SGH S500	SGH-A200	SGH-A288	SGH-A300	SGH-A308	SGH-A400	SGH-A408
SGH-A500	SGH-A608	SGH-A800	SGH-C100	SGH-C130	SGH-C207	SGH-C225
SGH-C417	SGH-D100	SGH-D307	SGH-D347	SGH-D357	SGH-D407	SGH-D415
SGH-D500	SGH-D600	SGH-D800	SGH-E100	SGH-E105	SGH-E300	SGH-E315
SGH-E316	SGH-E317	SGH-E330	SGH-E330N	SGH-E335	SGH-E350	SGH-E370
SGH-E400	SGH-E600	SGH-E630	SGH-E635	SGH-E700	SGH-E710	SGH-E715
SGH-E760	SGH-E770	SGH-E800	SGH-K528	SGH-N200	SGH-N400	SGH-N500
SGH-N620	SGH-N625	SGH-N628	SGH-P107	SGH-P207	SGH-P400	SGH-P408
SGH-P510	SGH-P735	SGH-Q100	SGH-Q200	SGH-Q208	SGH-Q300	SGH-R200
SGH-R208	SGH-R210	SGH-R210S	SGH-R220	SGH-R225	SGH-R225M	SGH-S100
SGH-S200	SGH-S208	SGH-S300	SGH-S300M	SGH-S307	SGH-S308	SGH-T100
SGH-T108	SGH-T200	SGH-T208	SGH-T209	SGH-T309	SGH-T319	SGH-T400
SGH-T408	SGH-T410	SGH-T500	SGH-T609	SGH-T619	SGH-T709	SGH-T719
SGH-V100	SGH-V200	SGH-V205	SGH-V206	SGH-X100	SGH-X105	SGH-X426
SGH-X427	SGH-X427M	SGH-X450	SGH-X460	SGH-X475	SGH-X480	SGH-X495
SGH-X497	SGH-X507	SGH-X600	SGH-X640	SGH-X660		

Treo

600	650	700	700w
-----	-----	-----	------