

Note: The 12V regulator has 40mA power consumption. Plug the regulator when using the battery, unplug the regulator when not using the battery. Otherwise, the power will be used up very soon.

When plug the regulator to the battery, Vout pin from the regulator to red wire of 4 pin connector on the battery.

